

[cheatsheet](#), [3ware](#), [twcli](#), [raid](#), [controller](#), [cli](#), [raidcontroller](#)

# 3Ware tw\_cli Cheat Sheet

## Sources

- [https://www.sysadminslife.com/linux/howto-3ware-raid-status-anzeigen-und-festplatte-tauschen-mit-tw\\_cli/](https://www.sysadminslife.com/linux/howto-3ware-raid-status-anzeigen-und-festplatte-tauschen-mit-tw_cli/)
- [https://www.thomas-krenn.com/de/wiki/3Ware\\_CLI\\_Einf%C3%BChrung](https://www.thomas-krenn.com/de/wiki/3Ware_CLI_Einf%C3%BChrung)
- [https://www.thomas-krenn.com/de/wiki/RAID\\_Status\\_abfragen#3ware](https://www.thomas-krenn.com/de/wiki/RAID_Status_abfragen#3ware)
- [https://www.cyberciti.biz/files/tw\\_cli.8.html](https://www.cyberciti.biz/files/tw_cli.8.html)
- [https://getmoven.com/index.php/knowledgebase/43/tw\\_cli-3ware-Command-Line-Utility.html](https://getmoven.com/index.php/knowledgebase/43/tw_cli-3ware-Command-Line-Utility.html)

/opt/3ware/CLI/tw\_cli

Command	Description
bash; gutter: false>/c0 add type=raid5 disk=0-4	create RAID5 with disks 0-4
bash; gutter: false>/c0 add type=raid5 disk=0-4 name=Data autoverify storsave=perform	create RAID5 with disks 0-4, with name "data", "autoverify" set to "on", "Storesafe" set to "performance"
bash; gutter: false>/cx add type=spare disk=x	add a hot spare to a controller (must have at least the same capacity as the biggest disk connected to the controller)
bash; gutter: false>/c0 show	show basic info about the controller, connected disks and BBU
bash; gutter: false>/c0/u0 show	display information about a specific unit
bash; gutter: false>/c0 show alarms	display alarm messages
bash; gutter: false>tw_cli /c0 show diag > diag.txt	prints diagnostic information and writes it to a file
bash; gutter: false>help	displays list of available commands
bash; gutter: false>/c0 help	
bash; gutter: false>/c0/u0 help	
quit	

From:  
<https://wiki.nanoscopic.de/> - nanoscopic wiki

Permanent link:  
[https://wiki.nanoscopic.de/doku.php/pages/cheatsheets/3ware\\_tw\\_cli?rev=1612002046](https://wiki.nanoscopic.de/doku.php/pages/cheatsheets/3ware_tw_cli?rev=1612002046)

Last update: 2021/01/30 10:20

